


Quick Reference Guide

Parts Descriptions


VE-GP10 Base Unit



- 1** Handset
- 2** Speaker
- 3** Outside call indicator
Intercom indicator
Doorphone indicator
- 4** Voice select button
- 5** Playback/Call Record button
- 6** Antenna
- 7** Auto Answer button & indicator
- 8** One-touch Dial buttons
- 9** Set button
- 10** Confirm button
- 11** Redial button (再ダイヤル)
- Short cut button (ショートカット)
- Volume control buttons (音量)
- 12** Cancel button
- 13** Flash/Erase button
- 14** Intercom button
- 15** Hold button
- 16** Monitor button
- 17** Numeral buttons
- 18** Tone button (to switch to DTMF tone)

KX-FKN523 Personal Phone

Backside View



- 1** Earpiece
- 2** Talk button
- 3** Speakerphone button
- 4** Numeral/Character buttons
- 5** Tone button (to switch to DTMF tone)
- 6** Flash/Clear button
- 7** Microphone
- 8** Liquid crystal display
- 9** Voice change button
- 10** Multi-operation buttons
- 11** Redial button (再ダイヤル)
- Phone book button (電話帳)
- Volume control button (音量)
- 12** Off button
- 13** Hold/Caller ID button
- 14** Intercom/Character entry mode button
- 15** Speaker
- 16** Battery cover

■ 本機は日本国内用です。国外での使用に対するサービスは致しかねます。
 ■ This product is designed for use in Japan.
 Panasonic cannot provide service for this product if used outside Japan.

Basic Operations

- The number after the button shows the location of the button described in the previous page.

Base unit (VE-GP10)

■ To make a call

Lift the handset. → Dial.

■ To receive a call

When the phone rings... → Lift the handset.

■ To place the current call on hold

Press (15) during a call.

(You can place the handset on the base unit.)

■ To retrieve the held call

- If you have returned the handset on the base unit, lift the handset.
- If you have not returned the handset on the base unit, press again.

■ To transfer the held call to the personal phone

Press (14) during a call. (→ When you use multiple personal phones, press - (Intercom No.).) → Place the handset on the base unit when the other party answers.

■ To use TAM (Telephone Answering Machine)

When you leave home, press (7) to turn on the indicator.

(To deactivate, press again to turn off the indicator.)

→ When receiving a call while TAM is activated, it answers the call automatically in Japanese, and records the incoming messages.

Then, the indicator starts flashing.

→ When you return home, press to play back the messages.

The indicator turns off and the answering mode is deactivated.

To erase the message, press (13) while listening to the message you want to erase.

To play back the message while TAM is deactivated, press (5).

*Up to 50 messages can be recorded for approx. 12 minutes in total.

Personal phone (KX-FKN523)

■ To make a call

Lift the personal phone from the charger and press (2). → Dial.....To end the call, place the personal phone on the charger or press (12).

■ To receive a call

When the phone rings... → Lift the personal phone from the charger or press . →

Talk.....To end the call, place the personal phone on the charger or press .

■ To make a call using the speakerphone (Hands-free talk)

Press (3). → Dial. → Talk to the microphone.....To end the call, place the personal phone on the charger or press .

■ To receive a call with the speakerphone (Hands-free talk)

When the phone rings... → Press .

→ Talk to the microphone.....To end the call, press .

■ To place the current call on hold

Press (13) during a call.

■ To retrieve the held call

Press or .

■ To transfer the held call to the base unit

Press (14) during a call. (→ When you use multiple personal phones, press .) → Place the personal phone on the charger, or press when the other party answers.

■ To transfer the held call to another personal phone

Press during a call. → Press - (Intercom No.). → Place the personal phone on the charger, or press when the other party answers.

■ To hear recorded messages while away from home (Remote control)

Preparation before you leave home

Store a remote control number.

Press

. → Enter the desired 4-digit number. → Press , then press . When you leave home, press to turn on the indicator.

To hear messages

Dial your home phone number. → While the outgoing message is played back...

→ Enter your remote control number.

→ Announcement → Press . → You will hear recorded messages if any.

NOTE

- This operation can be made only from telephones which can send DTMF signals.